



# POP STAR

## Silicone Popcorn Popper

- ★ HEALTHY ALTERNATIVE TO PREPACKAGED POPCORN
- ★ EASY TO USE
- ★ SPACE SAVER
- ★ DISHWASHER SAFE

## Instructions

1. Wash bowl before use
2. Expand the bowl to it's full height
3. Add 1/4 cup (bottom line inside bowl) to 1/2 cup (top line inside bowl) of kernels
4. Place lid loosely on top of bowl
5. Microwave for 2-4 minutes, until popping slows (approximately 5 seconds between pops)
6. Carefully remove bowl using handles (CAUTION: May be hot)
7. Carefully remove the lid (CAUTION: hot steam will be underneath the lid)
8. Season to taste & Enjoy!

## Precautions

1. Use with adult supervision only.
2. Do not leave unattended while cooking popcorn kernels.
3. Popcorn kernels may burn if overcooked.
4. Make sure no other grains are mixed with the popcorn kernels before heating. Heating other kinds of kernels may cause burning.
5. Do not pour in kernels above the upper fill line located in the bottom of the bowl.